

EntraFlo H2O Feeding Pump Education Videos

Video Description	QR Code- Open Camera on phone to scan code
<p>1. EntraFlo H2O – Standard Set Up (10min) - https://youtu.be/Pr4a2IY3BMA Always program the pump before priming.</p>	
<p>2. Maximum Water Rates (2min) – https://youtu.be/2xAOtQwVGG4 Maximum water that can be delivered is 75mL per hour continuously. Programed 150mL / 2 hours. 150 mL will be delivered over 2 hour time interval and repeat as long as the feeding side is still running. Any additional water will need to be given manually and manually added to the totals in the chart.</p>	
<p>3. Priming (4min) – https://youtu.be/s8-MxUIWIMl Clamp feeding sets before spiking feeding container or pouring water into the bag. Load completely dry drip chambers into the feeding pump. Close the doors, unclamp, and press PRIME. Priming takes 3 minutes. Do not manipulate the pump to make it prime faster. Pump will alarm when prime is complete.</p>	
<p>4. Changing Feeding Rate (1min) -- https://youtu.be/0cqzVXMGJHc When resetting the volume delivered on the feeding side the volume delivered on the water side resets automatically and the time interval restarts. If this occurs in the middle of a time interval the person may not have gotten their 25mL automatic quick flush and will be short on their total water volumes. Always check water volume delivered and water accumulated before resetting the volume delivered.</p>	
<p>5. Alarm Settings (3min) – https://youtu.be/Ww1Rbo_IFIs</p> <ol style="list-style-type: none"> 1. No Set- must load EntraFlo H2O set on both sides 2. Feed Err – watch to learn reasons for feed error 3. Low battery- plug in the pump 4. Dose DeL- watch video to learn change alarm frequency 5. Hold Err- pump has been paused for longer than 2 ½ min 	

EntraFlo H2O Feeding Pump Education Videos